## **ΟΝΟ ΣΟΚΚΙ**

### DS-0321 FFT Analysis Software

**Operation manual** 

for Acoustic Analysis Using MI Series Measurement Microphone

ONO SOKKI CO., LTD.



This instruction manual describes basic operations of the MI series measurement microphone for acoustic analysis.

As in the system configuration shown in the figure below, the MI-1433 1/2 inch measurement microphone with MI-3111 preamplifier is connected to Ch1 of the DS-3000 (with Ch2 unused), FFT analysis is executed using DS-0321 FFT analysis software.

This manual describes functions with the focus on what behavior will result from a single operation, and you are recommended to try various actions on the instrument.

Basic operations of DS-3000 software are mostly executed in the Configuration window. As the operations in the Configuration window are correspondent with those of the Main menu, the Main menu operations are not included in this manual. For details on the Configuration window operations, refer to the respective procedure manuals (Basic operation procedure for display of Configuration Window and Basic operation procedure for Configuration Setting).

In this instruction manual, a series of clicking operations is described, for example, as follows: Click "File" > "Project File" > "New Project" > "Exec\_".

### System Configuration



MI-1433 1/2-inch measurement microphone with MI-3111 preamplifier

## **ΟΝΟ ΣΟΚΚΙ**

### Operation Flow

- -1 Startup
- -2 Opening a New Project
- -3 Change the Number of Screen Partitions
- -4 Setting the Input Source
- -5 Setting CCLD
- -6 Starting and Stopping Measurement
- -7 Calibrating the Measurement Units
- -8 Setting the Voltage Range
- -9 Setting the Frequency Range



### Operation Procedure

#### -1 Startup

Connect each device as described in the System Configuration, turn power on, and start the DS-0321 FFT analysis software.

#### -2 Opening a New Project

① Click "View" > "Configuration" from the Main menu to open the "Configuration" window.



② In the "Configuration" window, click "File" > "Project File" > "New Project" > "Exec". This operation discards the current settings and opens a new project with the initial settings.

The?     Measurement Control     Early     Park/Column Entrol     Data Data String     Meddelly     Vendorelly     Column     Height     -       Image: The Column     STOP     Image: Column     STOP     Image: Column     STOP     Image: Column     Stop     <	đΧ
THE ANS START PUSS STOP RC THIS SCHED SIGN SIGN D.C	
	09000
Frequency Ravee 2014b 🥪 Sampling Condition Internal 🐱 Averaging Mode I Power Sum 🐭 Averaging Count 10 🔤 Trigger Mode Repost 💓 Sampling Point Count 2048 💓 Averaging Condition Count 💓 Averaging Time 10 🔲	
0 CH1 ♥ Power Spectrum ♥ Mag ♥ 0 (CH1 ♥ Power Spectrum Neg ♥ 0 (C	Ouston
2 Project File	
Open Project Open	E.
Save Project Open	<b>1</b> 3
Project Setting CNDocuments and Settings CNDocuments and Settings	
▶ Mess Data File	
▶ Record File	
Open Ottline Analysis Data Open 👻 -50	
▶ Print	
Exit Exec	
Meas Control -70	
▶ Ede	
► input/Dutput Setting	
Analysis Setting	
Data Disp Setting X 2.025kHz YL-91.0000Vk	
▶ Mode	
▶ View	
Window OUT: Power Spectrum Mag	
▶ Option	
▶ Heb	
-20	
@ -30	
-70	
no nobor 10000 20000 <sup>190</sup> 0 2000 <sup>10</sup> 4000 6000 8000 10000 12000 14000 16000 2000	0
X 2.829.Hz Y -91.3868W	
X-axis Zoom Lin V	

# 

#### -3 Change the Number of Screen Partitions

① Click the Select Number of Partitions tool "III" above the graph window, and select the two partitions of the upper and lower ones as shown in the figure below. This results in two screen partitions.



The graph numbers are automatically assigned to sequence numbers in the upper left to right order while changing the row ("Graph 1", "Graph 2", and so on) You can view the graph number by clicking "Set Data View" > "Set Graph Format" > "Active Graph Number" in the "Configuration" window.





#### -4 Setting the Input Source

Set the graph in the upper screen partition to the "Ch1 Time Waveform" view. Set that in the lower partition to the "Ch1 Power Spectrum" view.

- ① Click in the upper graph to activate it. The graph is enclosed with orange box lines.
- ② Select "CH1" using the Select Input Source tool above the graph window. From the pull-down menu on the right to it, select "Time Waveform".



③ In a similar manner, click in the lower graph, select "CH1" for the input source, and select "Power Spectrum" for the display waveform.



- When you click in the graph, it is enclosed with orange box lines to show that it is active.
- The settings in the "Configuration" window are reflected in the active screen partition, except for the measurement items related to all the channels, including the frequency and voltage ranges.
- No operations are permitted on some items unless the system is in the "STOP" state. For example, the character string indicating the average number of process times grays out during averaging measurement, meaning that the setting is unchangeable.



#### -5 Setting CCLD

- In the "Configuration" window, click "Set I/O" > "Set Input" > "Open". The "Set Input Conditions" dialog box opens.
- ② In the "Set Input Conditions" dialog box, put a check mark in the "CCLD" box of "CH1". This allows power of "+24V/4mA" to be supplied from CH1 to the MI-1433 1/2 inch measurement microphone with MI-3111 preamplifier; the signal will be input properly.



#### -6 Starting and Stopping Measurement

① Start or stop the measurement using the "START" or "STOP" button on the main tool bar. If the waveform displayed is small, you need to adjust the voltage range according to Step 8. The following figure shows the noise waveforms measured. The time waveform is in the upper partition ("Graph 1") and its power spectrum is in the lower partition ("Graph\_2").





#### -7 Calibrating the Measurement Units

Calibrate the measurement units so that the reading along the Y axis can be directly read in the sound pressure level (dB) in the "START" status.

- Input the reference signal from the acoustic calibrator SC-2120. Turn on the power to the acoustic calibrator SC-2120 and slowly insert the microphone MI-1433 all the way to the bottom. Wait about 30 seconds for the sound pressure of the acoustic calibrator to stabilize.
- ② In the "Configuration" window, click ""Set I/O" > "Calibrate Measurement Units" > "Open". The "Set Calibration" dialog box opens.
- ③ Put a check mark in the "EU" box of "CH1" in the "Set Calibration" dialog box. Then, click the "Unit Name" key-in button to open the "Enter Character String" window, key in the unit name, and click the OK button. In the following figure, the pressure unit "Pa" is entered. Unit in a time waveform display is "Pa", "dBPar" in a power spectrum display. If you want to omit the pressure unit (Par) from the indication, leave the unit name field blank.



# <u>ονοζοκκι</u>

④ Click the "EU/SP" tab in the "Set Calibration" dialog box. The calibration setting dialog box of "EU/SP" opens.

anosokki DS-3000(0S-0320)	- [Window 1]						E	
Eile(E) Measurement Control(C)	Edit(E) Janual (Dudnut Su	ating(1) Anabusis(A) Data	Dire Satting(D) Mode(M)	View00 Window000	Ontines(0)	Halo00		<i></i>
				THE DE LEADER	49.000 (2)		_	
	PAUSE STOP REC		a 🖋 🚓 🖓 🖓 🖓 ແລະ			0.0	r/min L-1000	U8000
Frequency Range 20kHz 💌	Sampling Condition	ternal 💌 Averaging Mode	Power Sum 💌	Averaging Count 10				
Trigger Mode Repeat 💌	Sampling Point Count 20	48 🛛 🔀 Averaging Conditi	n Time 💌	Averaging Time 5				
Configuration	4		Current-3D Sch	adula Schedula-20	СН1 💙 Т	54	Real V	
	(III)	8-						2
k File		CH1: Time R						- 8
Meas Control								1 📑
▶ Edit		1						
Input/Output Setting								8
System Setting	Open	05						g
<b>Cross Combination Setting</b>	Open							
▶ Freq Range Setting	20kHz							
▶ Input Setting	Open	Unit/Calib. EU/SP						
Sampling Condition Setting	Internal					Source CH		
Rotation Input Setting		o CH1: Power Spe	ctrum Mag			addree on		
Trigger Condition Setting	Repeat					Voltage Range	1Vrmc M	
Unit/Cal Setting	Open	-10				Unit Name	Pa •	
Window Function Setting	Open					0 dB Beference V	alue 2E-05	
▶ Time-axis Preprocessing Setting	Open	-20						
Averaging Setting	Power Sum	a -30						
Schedule Setting	Ópen	8				Frequency Range	20kHt 🗸	
Sig Output Setting	Open							
Analysis Setting		a -m				Lin/Log	Log 🖌	
Data Disp Setting		· ~						
▶ Mode		-60 is i					_	
View		114906				X 🕨 🔳		
▶ Window		-70 -11 11				Averaging Time	5	
▶ Option		بنالاللبالي	et. All (Million 1997)					_
▶ Help		0 2000 40	0 6000 8000 10000	12000 14000 16000	18000 20000	Calibration Value	1	
		V Owned V -20	H2 (Hann			Everyte Cal		
		A Overall 1oc	430B W			Execute our		
							IK Car	vcel
		-60200 X 0.0000Hz Y.	4000 -380036V+ (₩) 0015 ▼▲▼	0000 10000 Hz Otanni X-axis Zoom Lin	12000	14000 16000	19000 20	] ‱

- (5) Press the "START" button in the main toolbar to start measurement.
- (6) Move the cursor to the "overall" position in the calibration setting dialog box of "EU/SP". Click in the window near the overall position and red line appears. Using the left and right arrow keys on the keyboard, move the cursor to align with the red line. At this time, "X: Overall" is displayed at the bottom of the window.



⑦ Set the calibration sound pressure of the acoustic calibrator SC-2120 (provided in the test chart of the acoustic calibrator). Specify the sound pressure in "Calibration Value" (94 dB/Pa in the following

# <u>ονοζοκκι</u>

example) at the right side of the calibration setting dialog box of "EU/SP" and click the "Execute calibration" button. At this time, "X: Overall Y: 94.000 dB Par" is displayed at the bottom of the dialog box. This confirms that the calibration has been executed. If you want to omit the pressure unit ("Pa") from the indication, leave the unit name field blank.



- ⑧ Click the OK button at the lower right of the calibration dialog box of "EU/SP" to return to the measurement window.
- (9) Confirm the acoustic calibration signal. Set the cursor setting tool to "Search" at the lower left of the graph window and align the cursor with the overall position in the same way as step (6) above. The successful calibration can be reconfirmed by confirming that "X: Overall Y: 94.000 dB Par" is displayed at the bottom of the window.



- 1 Turn off the power to the acoustic calibrator SC-2120 and remove the microphone MI-1433 from the acoustic calibrator.
- ① Attach the microphone MI-1433 to the measurement point.
- 1 If you want to omit the pressure unit (Par) from the indication, leave the unit name field blank.



#### Setting the Voltage Range

Adjust the voltage range to be suitable for the input signal. When the input signal exceeds the range, the "CH1" signal lamp changes to red. You must change it so that it will not be exceeded.

- ① Click the START button in the main toolbar.
- ② In the "Configuration" window, click " Input/Output Setting " > " Input Setting " > "Voltage Range Setting". Then, by using the ▲ or ▼ button of "CH1", adjust the voltage range to be suitable for the input signal.



#### -8 Setting the Frequency Range

While observing the displayed power spectrum, set the frequency range you want to analyze.

① In the "Configuration" window, click "Input/Output Setting " > "Freq Range Setting", and select the frequency range for analysis from the pull-down list displayed. In the following figure, "1 kHz" is set for the frequency range.



• For the analysis method and display, see operational procedure step 9 and after in the "Noise Analysis



Instruction Manual".

Notes:

- 1. The copyright of this procedure manual is owned by ONO SOKKI CO., LTD.
- 2. Reproduction without permission is prohibited.
- 3. This operation manual describes the procedure for general measurement and the publisher has no responsibility for data obtained by the customer during operation.