



IC MEMORY CARD

Replace the label depending on the option.


Strap (standard accessory) attachment point




Side switch



(2.1)



Mounting portion for an extension unit



Instruction label for a memory card

Battery-cover (4 AA-type batteries are used.)

Weight: Approx. 710g(batteries included)
(Unit: mm)

CF-1200
ONO SOKKI