

## **Excitation • Vibration Measurement System**


## NP-3000/7000 Series (Built-in preamplifier type)



## NP-2000 Series (Charge output type)



## **GK Series**



- $^{\star}1$ : Can not be used with the NP-500 series. (There are some exceptions)
- \*2: Connects TEDS amplifier and the sensor which is not applicable to TEDS.