# Phase Difference Torque Detector TH series

The TH series torque detectors employ a new magnetic phase difference method. They have significantly higher measurement accuracy than the conventional torque detectors, offering fast signal output update speed. These detectors do not require rotation direction change, have strong noise withstanding capability, and are easy to use even at factories.



ONOJOKKI

## TH series torque detectors offer the torque detection methoh for the future

The TH series torque detectors employ a new magnetic phase difference method with improving functionality while maintaining the advantages of Ono Sokki's conventional torque detectors. You can design your machines with the same installation and axial dimensions as our SS series torque detectors. They incorporate high durability and long service life-the biggest features of our torque detectors.

The new magnetic phase difference method does not require AC power supply to an auxiliary motor for rotation direction change. Furthermore, the characteristic data of the detector can be automatically set up on the TH-5100 digital torque meter when the power is turned on.



\*3 The MP-981 magnetoelectric rotation detector is sold separately. Please consult us about combination.

\*4 Optional software

## Specification

## TH series Torque Detector

Model	Torque capacity	Applicable rotation range	Spring constant	Inertia moment
name	N•m	r/min	N•m/rad	kgm <sup>2</sup>
TH-1204	2	0 to 6000	1.67 x 10 <sup>2</sup>	6.95 x 10⁻⁵
TH-1504	5	0 to 6000	4.12 x 10 <sup>2</sup>	6.95 x 10⁻⁵
TH-1105	10	0 to 8000	7.75 x 10 <sup>2</sup>	7.7 x 10 <sup>-5</sup>
TH-1205	20	0 to 8000	1.57 x 10 <sup>3</sup>	7.7 x 10 <sup>-5</sup>
TH-1505	50	0 to 6000	6.18 x 10 <sup>3</sup>	1.19 x 10 <sup>-3</sup>
TH-1106	100	0 to 6000	1.27 x 10⁴	1.19 x 10 <sup>-3</sup>
TH-1206	200	0 to 6000	2.54 x 10 <sup>4</sup>	1.34 x 10 <sup>-3</sup>
TH-1506	500	0 to 6000	6.18 x 10 <sup>4</sup>	1.34 x 10 <sup>-3</sup>

: ±0.1% (display average value per 1-second, static calibration) Accuracy 180% of rated torque Critical torque

•Breakdown torque: 400% of rated torque

Influence of temperature on sensitivity: 0.02% / °C / F.S. Influence of temperature at zero point : 0.02% / °C / F.S. Operating temperature range : 0 to +40°C

•Storage temperature range : -20 to +60°C •Operating humidity range: 95%RH or less •Vibration resistance : 50m/s<sup>2</sup> or less

•Rotation detecting gear: Provided as standard accessory (60 P/R)

Supplied from the TH-5100 digital torque meter Power requirement : Instruction manual, calibration chart

Accessories

### Options

•Torque signal cable :TH cable

<ul> <li>Rotation signa</li> </ul>	l cable:MX-8100 series	
		٦

Model name	Length (m)	Model name	Length (m)
TH-0105	5	MX-8105	5
TH-0110	10	MX-8110	10
TH-0120	20	MX-8120	20

## Features

- High accuracy: ±0.1%/full scale
- Long service life: Non-contact phase difference method adopted in the rotating and the signal detecting sections
- Superior noise withstanding: Line driver output with strong noise immunity
- No rotation direction change (CW/CCW).
- High-speed analog output, updating every 50µs<sup>\*1</sup>
- Long distance cable extension up to 50m<sup>\*2</sup> (matching) not required)
- \*1 Response time: depending on time constant setting.
- \*2 The signal cable is sold separately.

## Detection principle of the New Magnetic Phase Difference Method



The above drawing shows the interior structure of the torque detector. It is configured with a rotating shaft, phase difference plates, where a drive coil and detection coils are located face to face. A magnetic signal that flows from the excited drive coil to the phase difference plates is converted into an electric signal by the two detection coils.

When torque is applied to a rotating shaft, the revolution torque is twisted. Change of torsion angle appears as a phase difference of magnetic flux in the magnetic circuit. The magnetic signal is converted into voltage signals by the two detection coils and amplifier while the drive coil is excited. And then, the TH-5100 torque meter calculates the torque value from the phase difference.

## ■ TH-5100 Digital Torque Meter

Model name	Product name			
TH-5100	Digital torque meter			
TH-0510	Power calculation display function			

Torque input section	on
Input signal	: Output signal from the TH-1000 series torque detector
Rotation speed inp	out section
Input signal	: Output signal from the MP-981 magnetoelectric rotation detector
Input frequency	: 1Hz to 100kHz
Power requirement	: 12 ±0.6 VDC, 100mA max.
Applicable connector	r: R03-PB6M (TAJIMI ELECTRONICS CO., LTD.)
Display section	
Display items	: Torque, rotation speed Status display; measurement ready (READY), torque signal input, rotation signal input
Display	: LED 7-segment
Display range	: Torque; -99999 to 99999 Rotation speed: 0 to 99999
Display unit	: Torque; N·m Rotation speed; r/min
Display accuracy (1	-second average value)
	: Torque; ±0.1% / F.S. ±1 count
	: Rotation speed; ±0.02% / F.S. ±1 count
<b>D</b>	(input frequency: 10 Hz or more)
Display / output upo	
	: 1s / 10s / external gate (TRIG IN signal)

## Applications

#### • Evaluation of opening and closing torques for OA equipment and mobile phone The TH series torque detectors can measure TH-1204 Rotation detecting gear Torque detector torque continuously, regardless rotation MP-981 Magnetoelectric direction. Change of torque at starting rotation detector rotation can be captured at much faster Reversible motor speed. Because the detector has a long service life and high stability, it exhibits RP-432Z-360P/R Coupling Rotation signal superior performance in durability tests. Rotary encode Torg Angle signal sia • Suitable for hinge torque of notebook PCs MX-8105 Signal cable (5m) Torque TH-0105 TH cable (5m) and mobile phones. Recording devices RP-008 Signal cable (5m) • For performance test of automobile parts in $\dot{\rm CW/CCW}$ direction, such as wipers, power windows and valves. JEĘ 100VAC > < 100VAC 0 360 degree RV-3150 Reversible counter Angle analog signal TH-5100 Digital torque meter Torque analog signal



The TH series torque detectors measure cogging torque in small motors with fast response capability.

Basic setting data of the detector can be set up on the TH-5100 torque meter automatically. No need to change condition setup when the detector is replaced.

- Measurement of cogging torque and detent torque in brushless motors, reluctance motors, stepping motors and other motors.
- Measurement of loss torque in winding machines, gear box, rotary switches and others.

Analog output sec The number of char		Output items Input format Output format	: Trigger output / READY output (measurement ready signal) : No-voltage contact input or logic input : No-voltage contact output
Update time Applicable connector <b>BCD output section</b> The number of chair Output update time Output format Applicable connector Applicable cable <b>RS-232C</b> Baud rate Functions Applicable cable <b>Remote function</b>	<ul> <li>Torque, rotation speed</li> <li>Isolated voltage output (Common is shared between 2 channels.)</li> <li>±10V</li> <li>Torque ;Selectable from 500ms, 63ms, 16ms or 1.6ms Rotation speed; 0.16ms</li> <li>±0.01% / F.S. / °C</li> <li>:50µs</li> <li>:CO2 type (BNC) plug</li> <li>n</li> <li>nnels</li> <li>:2 channels</li> <li>:Torque, rotation speed</li> <li>:1s / 10s / external gate (TRIG IN signal)</li> <li>:Positive logic open collector output</li> <li>:DX40-50P (HIROSE ELECTRIC CO., LTD)</li> <li>: PE3531609 (5m, open ended)</li> <li>:9600 bps (fixed)</li> <li>:Input of setup conditions, output of displayed value / setup status</li> <li>:AX-5022 (by Ono Sokki, 2m)</li> </ul>	General specifica Power requiremen Power consumption Isolation resistance Withstand voltage Operating temperatur Storage temperatur Outer dimensions Weight Accessories Options Power calculation Calculation: Pow Display Sele Disp Unit Accessories	tion t: 100 to 240VAC, 50/60Hz on: Approx. 12VA (100VAC) or less e: 500VDC at megohm 10MΩ or more : 1500 VAC, one minutes ature range : 0 to +40°C ure range : -10 to +55°C : 76 (W) x 142 (H) x 302 (D) mm (not including protruded section) : Approx. 2kg : Unit label, connector for remote, four rubber foots, power cable (1.9m), instruction manual display function (TH-0510) ver (W) = 2π/60 x torque (N-m) x rotation speed (r/min) ective display; Rotation (fixed), torque or power (selectable) play range ; -99999 to +99999
Input items	: Selectable torque polarity / trigger input / clear input		

## Outer Dimensions

### (Unit: mm)



## Dimensions

TH	А	В	С	D	Е	F	øG	Н	I	J	К	L	øM	N <sup>P9</sup>	0
1204, 1504	200	104	70	130	105	147	8 <sup>h6</sup>	17	32	50-0.2	25	15	10	-	-
1105, 1205	220	104	70	130	105	147	14 <sup>h6</sup>	27	32	50-0.2	25	15	10	5	3 <sup>+0.1</sup>
1505, 1106	300	150	115	200	170	207	25 <sup>h6</sup>	45	35	80-0.5	40	20	14	8	4 <sup>+0.2</sup>
1206, 1506	350	150	115	200	170	207	36 <sup>h6</sup>	70	35	80-0.5	40	20	14	10	5 <sup>+0.2</sup>

## TH-5100 Digital Torque Meter



• Microsoft<sup>®</sup> and Windows<sup>®</sup> are registered trademarks of Microsoft Corporation in the United States and other countries. All other company names and product names used in this brochure are the product names or registered trademarks of their respective holders.

## ono∫okki

## U.S.A

Ono Sokki Technology Inc. 2171 Executive Drive, Suite 400 Addison, IL. 60101, U.S.A Phone: +1-630-627-9700 Fax : +1-630-627-0004 E-mail : info@onosokki.net http://www.onosokki.net

## THAILAND

Ono Sokki (Thailand) Co., Ltd. 29/67 Moo 5 Tivanon Road, Pakkred, Nonthaburi 11120, Thailand Phone : +66-2-964-3884 Fax : +66-2-964-3887 E-mail : osth\_sales@onosokki.co.jp

## P.R.CHINA

Ono Sokki Beijing Office Beijing Jing Guang Center 3510 Hu Jia Lou, Chao Yang Qu Beijing 100020, P.R.China Phone : +86-10-6597-3113 Fax : +86-10-6597-3114 E-mail : onosokki@bbn.cn

## WORLDWIDE

• Outer appearance and specifications are subject to change without prior notice.

Ono Sokki Co., Ltd. 3-9-3 Shin-Yokohama, Kohoku-ku, Yokohama 222-8507, Japan Phone : +81-45-476-9712 Fax : +81-45-470-7244 E-mail : overseas@onosokki.co.jp

URL: http://www.onosokki.co.jp/English/english.htm